

Flexible Optical Injection Moulding of optoelectronic devices

Flexible Optical Injection Moulding of Optoelectronic Devices


World of Photonics, April 28th 2022, Munich





About us

We are an **innovation** and **technology centre** specialized in **research** and in providing **technological services** in the field of **MATERIALS**, **ADVANCED MANUFACTURING PROCESS** and **INDUSTRY 4.0**



www.aimen.es | aimen@aimen.es



Industry supported, private centre. Applied R&D in:





Sustainable Manufacturing Processes



FINAL EVENT FLOIM PROJECT

April 28th 2022 | HALL A5 - ROOM A51




9.30 to 9.40h	FLOIM: Flexible Optical Injection Moulding of optoelectronic devices AIMEN Technology Centre Nerea Otero	10.20 to 10.35h	Challenges in the machining of micro-optical mould inserts Fraunhofer IWU Jan Edelmann
9.40 to 9.55h	In-mould measurement for mechatronic compensation of positioning errors in injection overmoulding RECENDT Christian Rankl	10.35 to 10.45h	High-performance DLC-based mould patterning technology with high control over micro and nano features ADAMA Zahra Gholamvand
9.55 to 10.05h	Fiber-optic based metrology for nanometric measurement of micro-mould filling by a polymer ADAMA Majid Fazeli Jadidi	10.45 to 11.00h	PHABULOuS Pilot Line Association Jessica van Heck
10.05 to 10.20h	Femtosecond laser fabrication of volume and surface-relief micrometric phase gratings CEIT Mikel Gómez Aranzadi	11.00 to 11.30h	

Agenda



Goal and Technology advantages

Single step optoelectronics encapsulation with optical functionalities.



Advantages

- Improved optical path and efficiency.
- Avoids optomechanics, increasing robustness.
- No need for microoptics manipulation.
- Allows for more compact devices.
- Reduces manufacturing steps and costs.



Challenges

- Need for high accuracy positioning during injection.
- Faulty parts incur in higher costs.
- Need for high resolution manufacturing processes.
- Functionalities must be transferred to injected parts.







Inserts manufacturing with optical properties

- Direct laser writing
- Ion Implant Lithography
- Micro Machining
- MultiPhoton Polymerization



Single-step encapsulation with optical functionalities

- Injection overmoulding
- In-mould active positioning system
- OCT quality control
- Real-time mould filling
 measurement



Technology demonstrators

- Compact Fibre Optic
 Transceiver
- Scanning Head for Optical Encoder
- BackLight Unit for vehicles A pillar







Inserts manufacturing with optical properties

- Direct laser writing
- Ion Implant Lithography
- Micro Machining
- MultiPhoton Polymerization



Single-step encapsulation with optical functionalities

- Injection overmoulding
- In-mould active positioning system
- OCT quality control
- Real-time mould filling
 measurement



Technology demonstrators

- Compact Fibre Optic
 Transceiver
- Scanning Head for Optical Encoder
- BackLight Unit for vehicles A pillar

Demonstrators



FLOIM

1: Compact Fiber optic transceiver

- Higher data density transmission and fiber optics communication speeds.
- High productivity and in-mould alignment requirements.





2: Scanning Head for Optical Encoder

- More compact design, increased efficiency of illumination and improved signal to noise ratio.
- Will allow for higher positioning accuracy, meaning a breakthrough in the manufacturing industry.


3: Backlight unit for Flexible screen in vehicles A pillar for increased visibility


- Higher road safety, specially for pedestrians and bikers.
- High directionality and homogeneity required




- Optical Coherence Tomography provides information about heterogeneities, cracks and other defects within the injected material.
- A 3 degrees of freedom positioning system allows for compensation of alignment errors in the injection moulding cavity.
- Proper mould filling must be ensured to guarantee the desired optical functionalities of the product.










OCT measurement of injected optic

Alignment compensation schematic

Measuring system schematic



- Laser direct writing is a fast and repeatable manufacturing process.
- Micro machining can generate surfaces with optical quality roughness.
- Ion Implant Lithography provides excellent resolution and accuracy.




Laser micro/nanostructured mould insert



Optical quality set of micro machined lenses on mould inserts.






10 μm-period structures manufactured by Ion Implant Lithography.



- A fully functional Pilot Line will be assembled at HYBTRONICS facilities, to manufacture the FOT demonstrator.
- The pilot line includes all the necessary steps to produce functional FOTs, not only the injection moulding process.
- HYBTRONICS handles the Front-End part of the line (steps previous to Injection Moulding), UPC is in charge of the Injection Moulding
 process and the optical validation, while MASSO leads the Back-End part of the line.



BabyPlast 6/10 VP injection machine used at UPC Back end robot cell developed by MASSO & HYBTRONICS

Pilot Line Lay-out at HYBTRONICS facilities



Thanks for your attention

Nerea Otero Ramudo | Advanced Laser MicroManufacturing Applications Leader

notero@aimen.es

| +34 674 269 176

FLOIM

Consortium:





This project has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement No 820661 The FLOIM project is an initiative of the Factories of the Future Public Private Partnership